

Lifejacket light type Jack AF

Operation, Service and Maintenance Instruction.

Operation:

The light is an automatic water activated light type with a manual on/off switch, and a constant light type. It is activated by moving the activation arm around the corner clockwise thereby enabling the automatic mode. The light will then turn on, if in contact with water. After being activated, the light stays turned on disregarding the water contacts are lifted out of the water.

The light is deactivated by moving the activation arm around the corner anti clockwise. If the light after disruption is brought back to automatic mode, and water contacts are dry, splash water on the contacts and the light goes on again.

Activation and deactivation is clearly marked on the label.

Size: 85mm x 42mm x 16mm (LxWxH)

Height dome: 9mm

Weight: 56g

Material: polycarbonate

Waterproof

Battery: Lithium, 5 years storage life (-30°C to +65°C)

Operational life: minimum 8 hr.

Operational water temperature from -1°C to +30°C

Operational environmental temperature from -30°C to +65°C

Light intensity minimum 1.44 candela

Approvals: SOLAS MED 96/98/EC, USCG, TC, AMSA, RS



Service:

The light is completely sealed and tamper free. The battery inside is a lithium type, that requires no further service. On the label is clearly indicated manufacturing date and expiry date and it has a 5 year storage time.

Maintenance:

It is recommended during ship service to activate the lights shortly. Lights that do not ignite must be returned to the manufacturer for inspection. It is not possible to replace LED or batteries. The light is completely sealed.

Alcares recommend that, when an automatic light is stored in humid or wet conditions, the switch should be set to off, to avoid accidental activation of the light.

Disposal of used lights should be done in accordance to local regulations.